

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO

DATE 07-26-09 TIME 0013

INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Jail

DM 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .10 AC.
OR

Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~

- DM 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
DM 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
DM 4. Air blank completed.
DM 5. Calibration check completed. Test results 0. 97 AC.
DM 6. Air blank completed.
DM 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Daniel McGinnis 543/QAS# 33426

INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number: 80-001019

07/26/2009

00:13:43

Standard Lot#: 818201G

Last Changed By: D. MCGINNIS #8086

QAS: D. MCGINNIS #8086

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	00:14:10
Cal Check	0.097	00:14:29
Air Blank	0.000	00:14:59



Operator's Signature

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO

DATE 07-26-09 TIME 0017

INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Jail

DM 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- DM 1. Clock time check.
- DM 2. Date check.

OPERATIONAL TESTS

- DM 1. Alcohol-free subject test result 0. 000 AC.
- DM 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- DM 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- DM 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES DM NO _____

COMMENTS All OK

SIGNATURE Daniel McGinnis SIB/QAS # 33426

INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number : 80-001019

07/26/2009

00:21:07

Standard Lot#: 818201G

Last Changed By: D. MCGINNIS #8086

QAS: D. MCGINNIS #8086

YAVAPAI CSO

Operator: D. MCGINNIS #8086

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 09/09/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	00:21:58
Diagnostic Test	Pass	00:22:26
Air Blank	0.000	00:22:53
0.100 Cal Check	0.097	00:23:12
Air Blank	0.000	00:23:42
Subject Test	0.056*	00:26:50
Air Blank	0.000	00:27:22
Air Blank	0.000	00:27:49
Subject Test	XXX**	00:28:09
Air Blank	IPS***	00:28:18

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
 Location: YCSO PRESCOTT JAIL
 Serial Number : 80-001019
 07/26/2009 00:17:08

Standard Lot#: 818201G
 Last Changed By: D. MCGINNIS #8086
 QAS: D. MCGINNIS #8086
 YAVAPAI CSO
 Operator: D. MCGINNIS #8086
 YAVAPAI CSO

Subject: SQAP,TEST
 DOB: 09/09/1990
 Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	00:18:06
Diagnostic Test	Pass	00:18:33
Air Blank	0.000	00:19:01
0.100 Cal Check	0.097	00:19:19
Air Blank	0.000	00:19:49
Subject Test	0.000	00:20:19
Air Blank	ABT*	00:20:35
Air Blank	RFI**	00:20:46

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO
DATE 07-26-09 TIME 0028
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Jail

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .10 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 097 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Daniel McGinnis 843/215# 33426

INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number: 80-001019

07/26/2009

00:28:52


Standard Lot#: 818201G

Last Changed By: D. MCGINNIS #8086

QAS: D. MCGINNIS #8086

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	00:29:19
Cal Check	0.097	00:29:38
Air Blank	0.000	00:30:08


Operator's Signature 543/QAS #3346