

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO  
DATE 1-15-10 TIME 2130  
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott

- DM* 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .10 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- DM* 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
*DM* 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
*DM* 4. Air blank completed.  
*DM* 5. Calibration check completed. Test results 0. .017 AC.  
*DM* 6. Air blank completed.  
*DM* 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE

*Daniel McGinnis* S43/QAS# 33426

INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number: 80-001019

01/15/2010

21:30:08

-----  
Standard Lot#: 818201G

Last Changed By: D. RAISS #3693  
-----

QAS: D. MCGINNIS #8086

YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	21:30:36
Cal Check	0.097	21:30:55
Air Blank	0.000	21:31:24

  
Operator's Signature

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO  
DATE 1-15-10 TIME 2137  
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott

DM 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

DM 1. Clock time check.  
DM 2. Date check.

OPERATIONAL TESTS

DM 1. Alcohol-free subject test result 0. 000 AC.  
DM 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
DM 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
DM 4. Standard Calibration Check standard 0. 10 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES DM NO \_\_\_\_\_

COMMENTS All OK  
\_\_\_\_\_  
\_\_\_\_\_

SIGNATURE Daniel McGinnis 543/QAS# 33426

INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number : 80-001019

01/15/2010

21:33:46

Standard Lot#: 818201G

Last Changed By: D. RAISS

#3693

QAS: D. MCGINNIS

#8086

YAVAPAI CSO

Operator: D. MCGINNIS

#8086

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 09/09/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:34:51
Diagnostic Test	Pass	21:35:18
Air Blank	0.000	21:35:46
0.100 Cal Check	0.097	21:36:04
Air Blank	0.000	21:36:34
Subject Test	0.000	21:37:14
Air Blank	ABT*	21:37:20
Air Blank	RFI**	21:37:30

\*Sequence Aborted

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO PRESCOTT JAIL  
Serial Number : 80-001019  
01/15/2010

21:37:49

Standard Lot#: 818201G  
Last Changed By: D. RAISS #3693

QAS: D. MCGINNIS #8086  
YAVAPAI CSO

Operator: D. MCGINNIS #8086  
YAVAPAI CSO

Subject: SQAP,TEST

DOB: 09/09/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:38:53
Diagnostic Test	Pass	21:39:20
Air Blank	0.000	21:39:48
0.100 Cal Check	0.097	21:40:06
Air Blank	0.000	21:40:36
Subject Test	0.030*	21:43:44
Air Blank	0.000	21:44:16
Air Blank	0.000	21:44:43
Subject Test	XXX**	21:45:09
Air Blank	IPS***	21:45:16

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

\*\*\*Improper Sample

**Not a Successfully Completed Test Sequence**



INTOXILYZER 8000

Location: YCSO PRESCOTT JAIL

Serial Number: 80-001019

01/15/2010

21:46:56

-----  
Standard Lot#: 818201G

Last Changed By: D. RAISS #3693  
-----

QAS: D. MCGINNIS #8086

YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	21:47:24
Cal Check	0.097	21:47:42
Air Blank	0.000	21:48:12

  
Operator's Signature