

Copy

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NSB/5597 AGENCY Yavapai County Sheriff's
DATE 4/16/12 TIME 11:04:40
INTOXILYZER SERIAL # 80-01019 LOCATION ~~Prescott~~ Prescott Intex

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 093 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB/5597

DPS Form Exh G-2 (Rev 05-01)

Bottle SN#
25310100A1

exp. 10/1/2012

RECEIVED
APR 16 2012

INTOXILYZER 8000

Location: YCSO DUI TRAILER

Serial Number: 80-001019

Core Version: 8105.48

04/16/2012

11:04:40

Standard Lot#: 25310100A1

Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56

YAVAPAI YCSO

Operator: J. MURRAY #N56

YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	11:05:21
0.100 Cal Check	0.093	11:05:41
Air Blank	0.000	11:06:11

Preventative Maintenance
Performed -- Timer Reset