

**EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)**

**ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE**

QA SPECIALIST Murphy AGENCY Yavapai County Sheriff's Office
 DATE 11/20/13 TIME 08:59:07
 INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Intox Room

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
 OR
 Pour a standard alcohol concentration solution ✓ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.093 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murphy NSB/5597

INTOXILYZER 8000
Location: YCSO PRESCOTT
Serial Number: 80-001019
Core Version: 8105.48
11/20/2013

08:59:04

Standard Lot#: 32012100A1
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY 5597 #N56
YAVAPAI YCSO

Operator: J. MURRAY 5597 #N56
YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	09:00:12
0.100 Cal Check	0.093	09:00:33
Air Blank	0.000	09:01:02

Preventative Maintenance
Performed -- Timer Reset