

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murray AGENCY Yavapai County Sheriff's Office  
DATE 5/4/14 TIME 13:43:57  
INTOXILYZER SERIAL # 80-001019 LOCATION Arscott Office

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution        AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NS6/5597

INTOXILYZER 8000

Location: YCSO PRESCOTT

Serial Number: 80-001019

Core Version: 8105.48

05/04/2014

13:43:57

-----  
Standard Lot#: 15013100A2

Last Changed By: J. SLOWINSKI #6101  
-----

QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFF  
-----

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFF  
-----

Test	g/210L	Time
Air Blank	0.000	13:44:39
0.100 Cal Check	0.098	13:45:00
Air Blank	0.000	13:45:30

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Murray AGENCY Yavapai County Sheriff's Office  
DATE 5/4/14 TIME 13:45:56  
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Office

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.  
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.  
 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed  
 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.  
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS Returned from DPS Lab

SIGNATURE J. Murray NS6/5597

INTOXILYZER 8000  
Location: YCSO PRESCOTT  
Serial Number: 80-001019  
Core Version: 8105.48  
05/04/2014

13:45:56

---

Standard Lot#: 15013100A2  
Last Changed By: J. SLOWINSKI #6101

---

QAS: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Operator: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	13:47:01
Diagnostic Test	Pass	13:47:36
Air Blank	0.000	13:48:04
0.100 Cal Check	0.098	13:48:25
Air Blank	0.000	13:48:54
Subject Test	0.000	13:49:13
Air Blank	0.000	13:49:40
Wait	ABT*	
Air Blank	RFI**	13:49:59

\*Sequence Aborted

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO PRESCOTT  
Serial Number: 80-001019  
Core Version: 8105.48  
05/04/2014 13:50:04

---

Standard Lot#: 15013100A2  
Last Changed By: J. SLOWINSKI #6101

---

QAS: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Operator: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	13:50:49
Air Blank	RFI**	13:50:57

\*Improper Sample  
\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO PRESCOTT  
Serial Number: 80-001019  
Core Version: 8105.48  
05/04/2014

13:51:52

---

Standard Lot#: 15013100A2  
Last Changed By: J. SLOWINSKI #6101

---

QAS: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Operator: J. MURRAY5597 #N56  
YAVAPAI SHERIFFS

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	13:52:50
Diagnostic Test	Pass	13:53:25
Air Blank	0.000	13:53:53
0.100 Cal Check	0.098	13:54:14
Air Blank	0.000	13:54:43
Subject Test	0.088*	13:57:50
Air Blank	0.000	13:58:22
Air Blank	0.000	13:58:50
Subject Test	RGE**	13:59:22
Air Blank	0.000	14:00:02

\*Deficient Sample

\*\*Range Exceeded

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000  
Location: YCSO PRESCOTT  
Serial Number: 80-001019  
Core Version: 8105.48  
05/04/2014

14:10:53

---

Standard Lot#: 15013100A2  
Last Changed By: J. SLOWINSKI #6101

---

QAS: J. MURRAY5597 #N56  
YAVAPAI SHERIFF

---

Operator: J. MURRAY5597 #N56  
YAVAPAI SHERIFFS

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	14:11:56
Diagnostic Test	Pass	14:12:31
Air Blank	0.000	14:12:58
0.100 Cal Check	0.098	14:13:19
Air Blank	0.000	14:13:49
Subject Test	XXX*	14:16:45
Air Blank	IPS**	14:16:57

\*Invalid Sample  
Begin new deprivation period  
\*\*Improper Sample

Not a Successfully Completed Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murray AGENCY Yavapai County Sheriff's Office  
DATE 5/4/14 TIME 14:17:20  
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott Office

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.00 AC.  
OR  
Pour a standard alcohol concentration solution        AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 098 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB/5597

INTOXILYZER 8000

Location: YCSO PRESCOTT

Serial Number: 80-001019

Core Version: 8105.48

05/04/2014

14:17:20

-----  
Standard Lot#: 15013100A2

Last Changed By: J. SLOWINSKI #6101

-----  
QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

-----  
Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS  
-----

Test	g/210L	Time
Air Blank	0.000	14:18:00
0.100 Cal Check	0.098	14:18:21
Air Blank	0.000	14:18:50

Preventative Maintenance  
Performed -- Timer Reset



ARIZONA DEPARTMENT OF PUBLIC SAFETY

INTOXILYZER MAINTENANCE REPORT

AGENCY Yavapai County Sheriff's Office  
Prescott, AZ 86301

CR NO. I800010190002

Page 1 of 1

OFFICER MURRAY, #N56

DATE April 25, 2014

**INSTRUMENT:**

80001019

**INSTRUMENT LOCATION:**

Yavapai County Sheriff's Office

**MAINTENANCE REQUESTED:**

Repair and Preventative Maintenance

**MAINTENANCE PERFORMED:**

***Parts Replaced:***

Power Supply

***Preventative Maintenance Performed:***

Inspection, Calibration, Verification, Adjustment

A handwritten signature in black ink, appearing to read "Joseph M Slowinski".

---

JOSEPH M SLOWINSKI, #6101  
Electronics Technician  
Central Regional Crime Laboratory  
P. O. Box 6638  
Phoenix, AZ 85005  
(602) 223-2394

