

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murray AGENCY Yavapai County Sheriff's Office
DATE 2/20/16 TIME 18:15:30
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (+) 4. Air blank completed.
- (+) 5. Calibration check completed. Test results 0. 098 AC.
- (+) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray

INTOXILYZER 8000

Location: YCSO PRESCOTT

Serial Number: 80-001019

Core Version: 8105.48

02/20/2016

18:15:30

Standard Lot#: 36314100A4

Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Test	g/210L	Time
Air Blank	0.000	18:16:08
0.100 Cal Check	0.098	18:16:29
Air Blank	0.000	18:16:59

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. MURRAY AGENCY Yavapai County Sheriff's Office
DATE 2/20/16 TIME 18:17:31
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

06H/ SW # 36314100A4 exp-2/5/2017 850 PSI

SIGNATURE Murray

INTOXILYZER 8000
Location: YCSO PRESCOTT
Serial Number: 80-001019
Core Version: 8105.48
02/20/2016 18:17:31

Standard Lot#: 36314100A4
Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	18:18:27
Diagnostic Test	Pass	18:19:02
Air Blank	0.000	18:19:30
0.100 Cal Check	0.098	18:19:50
Air Blank	0.000	18:20:20
Subject Test	0.000	18:20:38
Air Blank	0.000	18:21:05
Wait	ABT*	
Air Blank	IPS**	18:21:20

*Sequence Aborted
**Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO PRESCOTT
Serial Number: 80-001019
Core Version: 8105.48
02/20/2016

18:22:14

Standard Lot#: 36314100A4
Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	18:22:51
Air Blank	0.000	18:23:20

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO PRESCOTT
Serial Number: 80-001019
Core Version: 8105.48
02/20/2016

18:23:50

Standard Lot#: 36314100A4
Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	18:24:58
Diagnostic Test	Pass	18:25:33
Air Blank	0.000	18:26:00
0.100 Cal Check	0.098	18:26:21
Air Blank	0.000	18:26:51
Subject Test	RGE*	18:27:19
Air Blank	0.000	18:27:54

*Range Exceeded

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO PRESCOTT
Serial Number: 80-001019
Core Version: 8105.48
02/20/2016 18:28:19

Standard Lot#: 36314100A4
Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56
YAVAPAI SHERIFFS

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	18:29:21
Diagnostic Test	Pass	18:29:56
Air Blank	0.000	18:30:23
0.100 Cal Check	0.097	18:30:44
Air Blank	0.000	18:31:14
Subject Test	0.244*	18:34:21
Air Blank	0.000	18:34:53
Air Blank	0.000	18:35:20
Subject Test	XXX**	18:35:48
Air Blank	0.000	18:36:21

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murray AGENCY Yavapai County Sheriff's Office
DATE 2/20/16 TIME 18:36:37
INTOXILYZER SERIAL # 80-001019 LOCATION Prescott

- (7) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (7) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (7) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (7) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.097 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray

INTOXILYZER 8000

Location: YCSO PRESCOTT

Serial Number: 80-001019

Core Version: 8105.48

02/20/2016

18:36:37

Standard Lot#: 36314100A4

Last Changed By: S. BLAKLEY SR #L6861

QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Test	g/210L	Time
Air Blank	0.000	18:37:17
0.100 Cal Check	0.097	18:37:38
Air Blank	0.000	18:38:08

Preventative Maintenance
Performed -- Timer Reset