

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Daniel McGinnis AGENCY YCSO
DATE 7-16-10 TIME 2204
INTOXILYZER SERIAL # 80-001095 LOCATION Mayer

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 10 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 097 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Daniel McGinnis 543/QAS# 33426

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
07/16/2010 22:04:56

Standard Lot#: 901401I
Last Changed By: D. MCGINNIS #8086

QAS: D. MCGINNIS #8086
YAVAPAI CSO

Operator: D. MCGINNIS #8086
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	22:05:34
0.100 Cal Check	0.097	22:05:55
Air Blank	0.000	22:06:24

Preventative Maintenance
Performed -- Timer Reset