

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JEFFREY R. JAEGER AGENCY YAVAPAI COUNTY SHERIFF'S OFFICE

DATE 08-26-2011 TIME 1332

INTOXILYZER SERIAL # 80-001095 LOCATION MAYER SUB-STATION

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.096 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  #3566

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 13:32:55

Standard Lot#: 20910100A1
Last Changed By: D. MCGINNIS #8086

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	13:33:31
0.100 Cal Check	0.096	13:33:51
Air Blank	0.000	13:34:21

Preventative Maintenance
Performed -- Timer Reset

CLOCK CHANGED 2 MINUTES AHEAD - MY CELLULAR PHONE

*NEW QAS - SGT. JEFFREY R. JAEGER #3566



EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST JEFFREY R. JAEGER AGENCY YAVAPAI COUNTY SHERIFF'S OFFICE
DATE 08-26-2011 TIME 1340
INTOXILYZER SERIAL # 80-001095 LOCATION MAYER SUB-STATION

(✓) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (✓) 1. Clock time check.
(✓) 2. Date check.

OPERATIONAL TESTS

- (✓) 1. Alcohol-free subject test result 0.000 AC.
(✓) 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
(✓) 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
(✓) 4. Standard Calibration Check standard 0.100 AC. Result 0.096 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE  #3566

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 13:40:06

Standard Lot#: 20910100A1
Last Changed By: D. MCGINNIS #8086

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 06/28/1985
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	13:41:47
Diagnostic Test	Pass	13:42:21
Air Blank	0.000	13:42:48
0.100 Cal Check	0.097	13:43:09
Air Blank	0.000	13:43:38
Subject Test	0.000	13:43:59
Air Blank	0.000	13:44:26
Wait	ABT*	
Air Blank	IPS**	13:47:49

*Sequence Aborted

**Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 13:49:24

Standard Lot#: 20910100A1
Last Changed By: D. MCGINNIS #8086

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 06/28/1985
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	13:50:34
Diagnostic Test	Pass	13:51:08
Air Blank	0.000	13:51:35
0.100 Cal Check	0.096	13:51:56
Air Blank	0.000	13:52:25
Subject Test	RGE*	13:53:00
Air Blank	0.000	13:53:37

*Range Exceeded

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 13:55:26

Standard Lot#: 20910100A1
Last Changed By: D. MCGINNIS #8086

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Subject: SOAP,TST
DOB: 06/28/1985
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	13:56:41
Diagnostic Test	Pass	13:57:15
Air Blank	0.000	13:57:42
0.100 Cal Check	0.097	13:58:03
Air Blank	0.000	13:58:32
Subject Test	XXX*	13:59:03
Air Blank	RFI**	13:59:14

*Invalid Sample
Begin new deprivation period
**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 13:59:35

Standard Lot#: 20910100A1
Last Changed By: D. MCGINNIS #8086

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 06/28/1985
Sex: M Weight: 175

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	14:00:35
Diagnostic Test	Pass	14:01:09
Air Blank	0.000	14:01:37
0.100 Cal Check	0.097	14:01:57
Air Blank	0.000	14:02:27
Subject Test	0.110*	14:05:34
Air Blank	0.000	14:06:06
Air Blank	0.000	14:06:34
Subject Test	ABT**	14:07:12
Air Blank	0.000	14:07:40

*Deficient Sample
**Sequence Aborted


Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JEFFREY R. JAEGER AGENCY YAVAPAI COUNTY SHERIFF'S OFFICE
DATE 08-26-2011 TIME 1408
INTOXILYZER SERIAL # 80-001095 LOCATION MAYER SUB-STATION

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.096 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  #3566

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
08/26/2011 14:08:49

Standard Lot#: 20910100A1
Last Changed By: J. JAEGER #3566

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	14:09:20
0.100 Cal Check	0.096	14:09:40
Air Blank	0.000	14:10:10

Preventative Maintenance
Performed -- Timer Reset

* STANDARD LOT # 20910100A1 EXP. 08-01-2012
VERIFIED BY SGT. JEFFREY R. JAEGER #3566