

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JEFFREY R. JAEGER AGENCY YAVAPAI COUNTY SHERIFF'S OFFICE

DATE 09-26-2011 TIME 1309

INTOXILYZER SERIAL # 80-001095 LOCATION MAYER SUB-STATION

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.097 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  #3566

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
09/26/2011 13:09:02

Standard Lot#: 20910100A1
Last Changed By: J. JAEGER #3566

QAS: J. JAEGER #3566
YAVAPAI CSO

Operator: J. JAEGER #3566
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	13:09:35
0.100 Cal Check	0.097	13:09:56
Air Blank	0.000	13:10:25

Preventative Maintenance
Performed -- Timer Reset

J. Jaeger #3566