

EXHIBIT G-2

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.

DATE 05/03/2012 TIME 1738

INTOXILYZER SERIAL # 80-001095 LOCATION YCSO-MAYER

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 097 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE LMOODY #7486

DPS Form Exh G-2 (Rev 05-01)

RECEIVED
MAY 07 2012

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPI CO. S.O.

DATE 05/04/2012 TIME 1740

INTOXILYZER SERIAL # 80-001095 LOCATION YCSO-MAYER

() 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- () 1. Clock time check.
- () 2. Date check.

OPERATIONAL TESTS

- () 1. Alcohol-free subject test result 0. 000 AC.
- () 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- () 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- () 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE

Logan Moody 67486

INTOXILYZER 8000
Location: YCSO-MAYER
Serial Number: 80-001095
Core Version: 8105.48
05/03/2012

17:40:59

Standard Lot#: 20910100A1
Last Changed By: J. JAEGER #3566

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/2000
Sex: M Weight: 190

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:41:50
Diagnostic Test	Pass	17:42:24
Air Blank	0.000	17:42:51
0.100 Cal Check	0.097	17:43:12
Air Blank	0.000	17:43:41
Subject Test	0.000	17:43:59
Air Blank	ABT*	17:44:06
Air Blank	RFI**	17:44:14

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO-MAYER

Serial Number: 80-001095

Core Version: 8105.48

05/03/2012

17:44:30

Standard Lot#: 20910100A1

Last Changed By: J. JAEGER

#3566

QAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/2000

Sex: M

Weight: 190

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	17:45:20
Diagnostic Test	Pass	17:45:54
Air Blank	0.000	17:46:22
0.100 Cal Check	0.097	17:46:43
Air Blank	0.000	17:47:12
Subject Test	0.057*	17:50:19
Air Blank	0.000	17:50:51
Air Blank	0.000	17:51:18
Subject Test	XXX**	17:51:45
Air Blank	IPS***	17:51:54

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***Improper Sample

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.
DATE 05/04/2012 TIME 1757
INTOXILYZER SERIAL # 80-001095 LOCATION YCSO-MAYER

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. .097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

INTOXILYZER 8000

Location: YCSO-MAYER

Serial Number: 80-001095

Core Version: 8105.48

05/03/2012

17:57:51

Standard Lot#: 20910100A1

Last Changed By: J. JAEGER #3566

QAS: L. MOODY #7486

YAVAPAI CSO

Operator: L. MOODY #7486

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	17:58:19
0.100 Cal Check	0.097	17:58:40
Air Blank	0.000	17:59:10

Preventative Maintenance
Performed -- Timer Reset