

18-028 796

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office
DATE 08/04/2018 TIME 1446
INTOXILYZER SERIAL # 80-001095 LOCATION YCSO - Mayer

- (C) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
~~Pour a standard alcohol concentration solution AC. into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (C) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (C) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (C) 4. Air blank completed.
- (C) 5. Calibration check completed. Test results 0. 098 AC.
- (C) 6. Air blank completed.
- (C) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody #7486