

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST D. Jacobs CV23 AGENCY Camp Verde Marshals office  
DATE 1/18/16 TIME 1607  
INTOXILYZER SERIAL # 80-001096 LOCATION DUI Trailer

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
(X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
(X) 4. Air blank completed.  
(X) 5. Calibration check completed. Test results 0. 098 AC.  
(X) 6. Air blank completed.  
(X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] CV23

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

01/18/2016

16:07:34

-----  
Standard Lot#: 33814100A1

Last Changed By: D. HUGHES #53  
-----

QAS: D. JACOBS #CV23

CAMP VERDE MO  
-----

Operator: D. JACOBS #CV23

CAMP VERDE MO  
-----

Test	g/210L	Time
Air Blank	0.000	16:08:31
0.100 Cal Check	0.098	16:08:52
Air Blank	0.000	16:09:22

Preventative Maintenance  
Performed -- Timer Reset