

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Deborah Hughes AGENCY Camp Verde Marshal's Ofc
DATE 7-27-17 TIME 0801 corrected to 0759
INTOXILYZER SERIAL # 80-001096 LOCATION Cumo-Booking

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 097 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature]

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

07/27/2017

07:59:18

Standard Lot#: 32316100A1

Last Changed By: D. JACOBS #CV08

QAS: D. HUGHES #63

CAMP VERDE MO

Operator: D. HUGHES #63

CAMP VERDE MO

Test	g/210L	Time
Air Blank	0.000	07:59:56
0.100 Cal Check	0.097	08:00:17
Air Blank	0.000	08:00:47

Preventative Maintenance
Performed -- Timer Reset