

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Sgt. D. Jacobs AGENCY Camp Verde Marshals office
DATE 4/1/18 TIME 0158
INTOXILYZER SERIAL # 80-001096 LOCATION CVMO Booking

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(✓) 4. Air blank completed.
(✓) 5. Calibration check completed. Test results 0.100 AC.
(✓) 6. Air blank completed.
(✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE _____ CV08

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

04/01/2018

01:58:06

Standard Lot#: 32316100A1

Last Changed By: D. JACOBS #CV08

QAS: D. JACOBS #CV08

CAMP VERDE MO

Operator: D. JACOBS #CV08

CAMP VERDE MO

Test g/210L Time

Air Blank 0.000 01:58:38
0.100 Cal Check 0.100 01:58:59
Air Blank 0.000 01:59:29

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Sgt. D. Jacobs AGENCY Camp Verde Marshals office
DATE 4/1/18 TIME 0200
INTOXILYZER SERIAL # 80-001096 LOCATION CVMO Booking

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 099 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE

[Signature] CV08

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

04/01/2018

02:00:01

Standard Lot#: 32316100A1

Last Changed By: D. JACOBS #CV08

QAS: D. JACOBS #CV08

CAMP VERDE MO

Operator: D. JACOBS #CV08

CAMP VERDE MO

Subject: TEST,TEST

DOB: 01/30/1980

Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:01:11
Diagnostic Test	Pass	02:01:45
Air Blank	0.000	02:02:12
0.100 Cal Check	0.099	02:02:33
Air Blank	0.000	02:03:03
Subject Test	0.000	02:03:21
Air Blank	ABT*	02:03:30
Air Blank	IPS**	02:03:38

*Sequence Aborted

**Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: CAMP VERDE MO
Serial Number: 80-001096
Core Version: 8105.48
04/01/2018

02:03:57

Standard Lot#: 32316100A1
Last Changed By: D. JACOBS #CV08

QAS: D. JACOBS #CV08
CAMP VERDE MO

Operator: D. JACOBS #CV08
CAMP VERDE MO

Subject: TEST,TEST
DOB: 01/30/1980
Sex: M Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	02:04:55
Diagnostic Test	Pass	02:05:29
Air Blank	0.000	02:05:57
0.100 Cal Check	0.099	02:06:18
Air Blank	0.000	02:06:47
Subject Test	0.029*	02:09:55
Air Blank	0.000	02:10:26
Air Blank	0.000	02:10:53
Subject Test	XXX**	02:11:36
Air Blank	RFI***	02:11:43

*Deficient Sample

**Invalid Sample

Begin new deprivation period

***RFI Detect

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL, 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Sgt. D. Jacobs AGENCY Camp Verde Marshals office
DATE 4/1/18 TIME 0213
INTOXILYZER SERIAL # 80-001096 LOCATION CVMA Booking

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] CV08

INTOXILYZER 8000

Location: CAMP VERDE MO

Serial Number: 80-001096

Core Version: 8105.48

04/01/2018

02:13:37

Standard Lot#: 32316100A1

Last Changed By: D. JACOBS #CV08

QAS: D. JACOBS #CV08

CAMP VERDE MO

Operator: D. JACOBS #CV08

CAMP VERDE MO

Test g/210L Time

Air Blank 0.000 02:14:08
0.100 Cal Check 0.098 02:14:29
Air Blank 0.000 02:14:58

Preventative Maintenance
Performed -- Timer Reset