

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)
ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST DAN RAISS AGENCY YAVAPAI Co. S.O.
 DATE 5-27-08 TIME 2245
 INTOXILYZER SERIAL # 80-001222 LOCATION YCSO-VERDE JAIL

- OK 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
 OR
 Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- OK 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- OK 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- OK 4. Air blank completed.
- OK 5. Calibration check completed. Test results 0. 100 AC.
- OK 6. Air blank completed.
- OK 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Marcelo Rain #5-31/DAS #33026

INTOXILYZER 8000

Location: YCSO-VERDE JAIL

Serial Number: 80-001222

05/27/2008

23:06:56

Standard Lot#: 633901I

Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	23:07:23
Cal Check	0.100	23:07:42
Air Blank	0.000	23:08:12

Daniel Q. Rain #5-31/QAS #33026

Operator's Signature

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST DAN RAISS AGENCY YAVAPAI CO-S.O.
DATE 5-27-08 TIME 2245
INTOXILYZER SERIAL # 80-001222 LOCATION YCSO-VERDE JAIL

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

XTRA MON BY OPERATOR ERROR. A L L O K.

SIGNATURE

Samuel Q Rains #5-31/DNS #33026

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number : 80-001222
05/27/2008

22:58:49

Standard Lot#: 633901I
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP,TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	22:59:29
Diagnostic Test	Pass	22:59:57
Air Blank	0.000	23:00:24
0.100 Cal Check	0.100	23:00:43
Air Blank	0.000	23:01:13
Subject Test	0.100*	23:04:21
Air Blank	0.000	23:04:53
Air Blank	0.000	23:05:20
Subject Test	XXX**	23:05:41
Air Blank	0.000	23:06:14

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number : 80-001222
05/27/2008 22:55:24

Standard Lot#: 633901I
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP, TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	22:56:07
Diagnostic Test	Pass	22:56:35
Air Blank	0.000	22:57:02
0.100 Cal Check	0.100	22:57:21
Air Blank	0.000	22:57:50
Subject Test	XXX*	22:58:10
Air Blank	0.000	22:58:44

*Invalid Sample
Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number : 80-001222
05/27/2008 22:54:27

Standard Lot#: 633901I
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP, TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	22:54:51
Air Blank	0.000	22:55:19

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number : 80-001222
05/27/2008 22:53:27

Standard Lot#: 633901I
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP,TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	22:53:51
Air Blank	0.000	22:54:20

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number : 80-001222
05/27/2008 22:48:17

Standard Lot#: 633901I
Last Changed By: D. RAISS #3693

QAS: D. RAISS #3693
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP, TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	22:49:45
Diagnostic Test	Pass	22:50:12
Air Blank	0.000	22:50:39
0.100 Cal Check	0.100	22:50:58
Air Blank	0.000	22:51:28
Subject Test	0.000	22:51:55
Air Blank	0.000	22:52:23
Five Minute Wait	ABT*	
Air Blank	0.000	22:53:09

*Sequence Aborted .

Not a Successfully Completed Test Sequence