

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST PT POOLE ESS AGENCY YAVAPAI COUNTY S-O  
DATE 6/8/13 TIME 1704  
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE JAIL

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
~~Pour a standard alcohol concentration solution AC into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START" STAND BY MODE
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE PT POOLE ESS

DPS Form Exh G-2 (Rev 05-01)

200 PSI

INTOXILYZER 8000

Location: YCSO-VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

06/08/2013

17:04:11

-----  
Standard Lot#: 15712100A1

Last Changed By: R. POOLE #9014

-----  
QAS: R. POOLE #9014

YAVAPAI CSO

-----  
Operator: R. POOLE #9014

YAVAPAI CSO

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      17:04:49  
0.100 Cal Check                0.098                      17:05:10  
Air Blank                      0.000                      17:05:39

Preventative Maintenance  
Performed -- Timer Reset