

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA-SPECIALIST RT POOLE AGENCY VALUAPAI COUNTY SHERIFF
DATE 10/3/13 TIME 0849
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE JAIL

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 099 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature]

DPS Form Exh G-2 (Rev 05-01)

MACHINE READ CONTACT OAS ON MENU. RESET TOWER AND PERFORMED
31 DAY SERVICE.
925 PSI

INTOXILYZER 8000
Location: YCSO-VERDE JAIL
Serial Number: 80-001222
Core Version: 8105.48
10/03/2013 02:49:18

Standard Lot#: 15013100A2
Last Changed By: R. POOLE #9014

QAS: R. POOLE #9014
YAVAPAI CSO

Operator: R. POOLE #9014
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	02:49:52
0.100 Cal Check	0.099	02:50:12
Air Blank	0.000	02:50:42

Preventative Maintenance
Performed -- Timer Reset