


EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST SEAN CHUPP AGENCY Y.C.S.O.
DATE 03/08/16 TIME 1220
INTOXILYZER SERIAL # 811-001222 LOCATION YAVAPAI COUNTY JAIL L.V.

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 100 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  E39/9808

356ps1

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

03/08/2016

12:20:29

Standard Lot#: 26614100A6

Last Changed By: S. CHUPP #9808

QAS: S. CHUPP #9808

YAVAPAI CSO

Operator: S. CHUPP #9808

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 12:21:01
0.100 Cal Check 0.100 12:21:21
Air Blank 0.000 12:21:51

Preventative Maintenance
Performed -- Timer Reset