

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Sean Chupp AGENCY YCSO  
DATE 04/19/16 TIME 0954  
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE JAIL

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
 4. Air blank completed.  
 5. Calibration check completed. Test results 0. 90 AC.  
 6. Air blank completed.  
 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 239/9808

DPS Form Exh G-2 (Rev 05-01)

200 PS 1

INTOXILYZER 8000  
Location: YCSO - VERDE JAIL  
Serial Number: 80-001222  
Core Version: 8105.48  
04/19/2016 09:57:29

-----  
Standard Lot#: 26614100A6  
Last Changed By: S. CHUPP #9808  
-----

QAS: S. CHUPP #9808  
YAVAPAI CSO  
-----

Operator: S. CHUPP #9808  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	09:58:03
0.100 Cal Check	0.098	09:58:24
Air Blank	0.000	09:58:53

Preventative Maintenance  
Performed -- Timer Reset