

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST SAAN CHOPP AGENCY VC SO
DATE 04/24/14 TIME 1839
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE SAIL

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 097 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  E39/9900

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

06/26/2016

18:39:37

Standard Lot#: 22315100A1

Last Changed By: J. DUBIEN #09611

QAS: S. CHUPP #9808

YAVAPAI CSO

Operator: S. CHUPP #9808

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	18:40:07
0.100 Cal Check	0.097	18:40:28
Air Blank	0.000	18:40:57

Preventative Maintenance

Performed -- Timer Reset