

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JASON DUBIEN AGENCY YAVAPAI C.S.O.
DATE 8/1/16 TIME 1526 HRS
INTOXILYZER SERIAL # 30-001222 LOCATION CAMP VERDE TAIL

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC. into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. DUBIEN 9611/E34

GAS 800 PSI

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

08/01/2016

15:26:38

Standard Lot#: 22315100A1

Last Changed By: E. BOONE #5823

QAS: J. DUBIEN #09611

YAVAPAI CSO

Operator: J. DUBIEN #09611

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	15:27:21
0.100 Cal Check	0.097	15:27:42
Air Blank	0.000	15:28:12

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST JASON DUBIEN AGENCY YAVAPAI C.S.O.
DATE 8/1/16 TIME 1530 HRS
INTOXILYZER SERIAL # 80-001222 LOCATION CAMP VERDE JAIL

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
() 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
() 4. Air blank completed.
() 5. Calibration check completed. Test results 0. 097 AC.
() 6. Air blank completed.
() 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. DUBIEN 9611/E34

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

08/01/2016

15:30:28

Standard Lot#: 22315100A1

Last Changed By: E. BOONE #5823

QAS: J. DUBIEN #09611

YAVAPAI CSO

Operator: J. DUBIEN #09611

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	15:31:02
0.100 Cal Check	0.097	15:31:22
Air Blank	0.000	15:31:52

Preventative Maintenance
Performed -- Timer Reset