

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Sean Chupp AGENCY YCSO
DATE 10/22/14 TIME 1334
INTOXILYZER SERIAL # 80-001222 LOCATION Camp Verde Trail

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 9008

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

10/22/2016

13:34:00

Standard Lot#: 22315100A1

Last Changed By: E. BOONE #5823

QAS: S. CHUPP #9808

YAVAPAI CSO

Operator: S. CHUPP #9808

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	13:34:32
0.100 Cal Check	0.097	13:34:53
Air Blank	RFI*	13:35:13
Air Blank	0.000	13:35:42

*RFI Detect

INTOXILYZER 8000

Location: YCSO - VERDE JAIL

Serial Number: 80-001222

Core Version: 8105.48

10/22/2016

13:36:48

Standard Lot#: 22315100A1

Last Changed By: E. BOONE #5823

QAS: S. CHUPP #9808

YAVAPAI CSO

Operator: S. CHUPP #9808

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 13:37:18
0.100 Cal Check 0.098 13:37:39
Air Blank 0.000 13:38:09

Preventative Maintenance
Performed -- Timer Reset