

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST R. Rivera 6354 AGENCY YAVAPAI CO. SO
DATE 2-21-18 TIME 2123
INTOXILYZER SERIAL # 80-001455 LOCATION BAGDAD

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 098 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE 

INTOXILYZER 8000
Location: YAVAPAI SO, BAGDAD
Serial Number: 80-001455
Core Version: 8105.48
02/21/2018 21:23:07

Standard Lot#: 27016100A1
Last Changed By: R. RIVERA #6356

QAS: R. RIVERA #6356
YAVAPAI CSO

Operator: R. RIVERA #6356
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	21:23:37
0.100 Cal Check	0.098	21:23:58
Air Blank	0.000	21:24:28

Preventative Maintenance
Performed -- Timer Reset