

18-025249

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST R. Rivera 6356 AGENCY YAVAPI CO. SO  
DATE 7-8-18 TIME 0036  
INTOXILYZER SERIAL # 80-001455 LOCATION Bagdad

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 098 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE 

18-025249

INTOXILYZER 8000

Location: YAVAPAI SO, BAGDAD

Serial Number: 80-001455

Core Version: 8105.48

07/08/2018

00:36:51

-----  
Standard Lot#: 27016100A1

Last Changed By: R. RIVERA #6356  
-----

QAS: R. RIVERA #6356

YAVAPAI CSO  
-----

Operator: R. RIVERA #6356

YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	00:37:25
0.100 Cal Check	0.098	00:37:46
Air Blank	0.000	00:38:15

Preventative Maintenance  
Performed -- Timer Reset