

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST DAN RAISS AGENCY YAVAPAI CO. S.D.

DATE 4-28-08 TIME 1205

INTOXILYZER SERIAL # 80-001456 LOCATION JCSO-YARNELL

- (Dk) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (Dk) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (Dk) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (Dk) 4. Air blank completed.
- (Dk) 5. Calibration check completed. Test results 0. 101 AC.
- (Dk) 6. Air blank completed.
- (Dk) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Daniel A. Raiss #5-31/DAS #33026

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 80-001456

04/28/2008

12:27:57

Standard Lot#: 730901I

Last Changed By: C. KROGEDAL #6535

QAS: D. RAISS #3693

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	12:28:24
Cal Check	0.101	12:28:43
Air Blank	0.000	12:29:13

David G. Ram #5-31/ONS #33026
Operator's Signature

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST DAN RAISS AGENCY YAVAPAI CO. S.O.
DATE 4-28-08 TIME 1205
INTOXILYZER SERIAL # 80-001456 LOCATION YCSO-YARNELL

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 101 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS All OK

SIGNATURE Dan Raiss #5-31 / OAS #33026

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number : 80-001456

04/28/2008

12:17:49

Standard Lot#: 730901I

Last Changed By: C. KROGEDAL

#6535

QAS: C. KROGEDAL

#6535

YAVAPAI CSO

Operator: D. RAISS

#3693

YAVAPAI CSO

Subject: SQAP,TEST,

DOB: 01/01/1901

Sex: M

Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:18:32
Diagnostic Test	Pass	12:18:59
Air Blank	0.000	12:19:26
0.100 Cal Check	0.101	12:19:45
Air Blank	0.000	12:20:14
Subject Test	0.147*	12:23:23
Air Blank	0.000	12:23:56
Air Blank	0.000	12:24:23
Subject Test	XXX**	12:25:05
Air Blank	0.000	12:25:40

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number : 80-001456

04/28/2008

12:16:28

Standard Lot#: 730901I

Last Changed By: C. KROGEDAL #6535

QAS: C. KROGEDAL #6535

YAVAPAI CSO

Operator: D. RAISS #3693

YAVAPAI CSO

Subject: SQAP,TEST,

DOB: 01/01/1901

Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	12:16:50
Air Blank	0.000	12:17:18

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI SO YARNELL
Serial Number : 80-001456
04/28/2008

12:15:25

Standard Lot#: 730901I
Last Changed By: C. KROGEDAL #6535

QAS: C. KROGEDAL #6535
YAVAPAI CSO

Operator: D. RAISS #3693
YAVAPAI CSO

Subject: SQAP, TEST,
DOB: 01/01/1901
Sex: M Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	12:15:48
Air Blank	0.000	12:16:17

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number : 80-001456

04/28/2008

12:08:59

Standard Lot#: 730901I

Last Changed By: C. KROGEDAL

#6535

QAS: C. KROGEDAL

#6535

YAVAPAI CSO

Operator: D. RAISS

#3693

YAVAPAI CSO

Subject: SQAP,TEST,

DOB: 01/01/1901

Sex: M

Weight: 1

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:10:27
Diagnostic Test	Pass	12:10:54
Air Blank	0.000	12:11:21
0.100 Cal Check	0.100	12:11:40
Air Blank	0.000	12:12:10
Subject Test	0.000	12:12:43
Air Blank	0.000	12:13:10
Five Minute Wait	ABT*	
Air Blank	0.000	12:13:45

*Sequence Aborted

Not a Successfully Completed Test Sequence