

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST RICHARD J. BYRNE III AGENCY AZ DPS

DATE 04/13/2014 TIME 1405

INTOXILYZER SERIAL # 80-001456 LOCATION YCSU - YARNELL SUBSTATION

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0.096 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Richard J. Byrne III # 6324

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 80-001456

Core Version: 8105.48

04/13/2014

14:05:41

Standard Lot#: 13712100A2

Last Changed By: D. ASHBY #S62

QAS: R. BYRNE III #6386

AZ DPS

Operator: R. BYRNE III #6386

AZ DPS

Test g/210L Time

Air Blank 0.000 14:06:18
0.100 Cal Check 0.096 14:06:39
Air Blank 0.000 14:07:09

Preventative Maintenance
Performed -- Timer Reset