

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO
DATE 9.28.15 TIME 0045
INTOXILYZER SERIAL # 80.001456 LOCATION Yarnell Substation

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 099 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Deann P Ashby #2271 / QAS #33400

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 90-001456

Core Version: 8105.48

07/28/2015

00:45:16

Standard Lot#: 36314100A4

Last Changed By: D. ASHBY #2271

QAS: D. ASHBY #2271

YAVAPAI CSO

Operator: D. ASHBY #2271

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 00:45:49
0.100 Cal Check 0.099 00:46:18
Air Blank 0.000 00:46:49

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO
DATE 9.28.15 TIME 0048
INTOXILYZER SERIAL # 80-001456 LOCATION Yarnell Substation

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. .100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

Instrument went over 30 days, as I was
on vacation. No problems detected with the
instrument.

SIGNATURE D. Ashby #2271 / QAS #33400

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 80-001456

Core Version: 8105.48

09/28/2015

00:48:12

Standard Lot#: 36314100A4

Last Changed By: D. ASHBY

#2271

QAS: D. ASHBY

#2271

YAVAPAI CSO

Operator: D. ASHBY

#2271

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/1999

Sex: M

Weight: 150

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 00:48:58 |
| Diagnostic Test | Pass | 00:49:33 |
| Air Blank | 0.000 | 00:50:01 |
| 0.100 Cal Check | 0.098 | 00:50:21 |
| Air Blank | 0.000 | 00:50:51 |
| Subject Test | 0.000 | 00:51:10 |
| Air Blank | 0.000 | 00:51:37 |
| Wait | ABT* | |
| Air Blank | 0.000 | 00:52:30 |

*Sequence Aborted

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 80-001456

Core Version: 8105.48

09/28/2015

00:52:34

Standard Lot#: 36314100A4

Last Changed By: D. ASHBY

#2271

QAS: D. ASHBY

#2271

YAVAPAI CSO

Operator: D. ASHBY

#2271

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/1999

Sex: M

Weight: 150

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | IPS* | 00:53:05 |
| Air Blank | 0.000 | 00:53:33 |

*Improper Sample

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI SO YARNELL
Serial Number: 80-001456
Core Version: 8105.48
09/28/2015 00:53:37

Standard Lot#: 36314100A4
Last Changed By: D. ASHBY #2271

QAS: D. ASHBY #2271
YAVAPAI CSO

Operator: D. ASHBY #2271
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1999
Sex: M Weight: 150

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------|--------|----------|
| Air Blank | RFI* | 00:54:08 |
| Air Blank | 0.000 | 00:54:36 |

*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YAVAPAI SO YARNELL
Serial Number: 80-001456
Core Version: 8105.48
09/28/2015 00:54:41

Standard Lot#: 36314100A4
Last Changed By: D. ASHBY #2271

QAS: D. ASHBY #2271
YAVAPAI CSO

Operator: D. ASHBY #2271
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 01/01/1999
Sex: M Weight: 150

15 Minute Deprivation Period? Yes

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 00:55:32 |
| Diagnostic Test | Pass | 00:56:07 |
| Air Blank | 0.000 | 00:56:35 |
| 0.100 Cal Check | 0.098 | 00:56:55 |
| Air Blank | 0.000 | 00:57:26 |
| Subject Test | 0.115* | 01:00:33 |
| Air Blank | 0.000 | 01:01:07 |
| Air Blank | 0.000 | 01:01:34 |
| Subject Test | XXX** | 01:02:15 |
| Air Blank | 0.000 | 01:02:51 |

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST D. Ashby #2271 AGENCY YCSO
DATE 9.28.15 TIME 0103
INTOXILYZER SERIAL # 80.001456 LOCATION Yarnell Substation

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0. 097 AC.
- (✓) 6. Air blank completed.
- (✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Dann Ashby #2271 / QAS#33400

INTOXILYZER 8000

Location: YAVAPAI SO YARNELL

Serial Number: 80-001456

Core Version: 8105.48

09/28/2015

01:03:56

Standard Lot#: 36314100A4

Last Changed By: D. ASHBY #2271

QAS: D. ASHBY #2271

YAVAPAI CSO

Operator: D. ASHBY #2271

YAVAPAI CSO

Test g/210L Time

Air Blank 0.000 01:04:06
0.100 Cal Check 0.097 01:04:47
Air Blank 0.000 01:05:17

Preventative Maintenance
Performed -- Timer Reset