

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST R. Rivera AGENCY YAVAPAI CO. SO

DATE 4-24-17 TIME 2207

INTOXILYZER SERIAL # 80-001456 LOCATION YARVELL

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 099 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE 

17-014320

INFORMATION 8000

Location: YAVAPAI SO TERRILL

Serial Number: 80-001456

Core Version: 8105.48

08/24/2017

20167.30

Standard Lot#: 2701610001

Last Changed By: D. ARBBI 12/21

QAS: P. RIVARA 4036

YAVAPAI CSO

Operator: P. RIVARA 4036

YAVAPAI CSO

Test 9/21/05 41m

Air Blank 0.000 12403.00

0.100 Cal Check 0.000 22180.01

Air Blank 0.000 22133.50

Preventative Maintenance
Performed -- Filter Reset

INTEGRIS/VER 3000

Location: YAVAPAI SO YAVAPAI

Serial Number: 00-001155

Core Version: 8105.13

04/22/2017

12:00:11

Standard Code: 2701610051

Last Changed By: E. AMER 2/2/11

QAS: R. RIVERA #6356

YAVAPAI CO

Operator: R. RIVERA #6356

YAVAPAI CO

Test	g/2105	Flow
Air Blank	0.005	22/05:24
0.100 Cal Check	0.098	22/05:29
Air Blank	0.014	22/06:00
Air Blank	3.004	22/07:27

*RPT Deleted