

COPY

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yuma Sheriff's  
DATE 12-14-10 TIME 11-04-15  
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman SO. Office

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution          AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0.098 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

12/14/2010

11:04:15

-----  
Standard Lot#: 779386

Last Changed By: J. MURRAY #N56  
-----

QAS: J. MURRAY #N56

YAVAPAI YCSO  
-----

Operator: J. MURRAY #N56

YAVAPAI YCSO  
-----

Test	g/210L	Time
Air Blank	0.000	11:04:53
0.100 Cal Check	0.098	11:05:14
Air Blank	0.000	11:05:43

Preventative Maintenance  
Performed -- Timer Reset