

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. MULLIGAN NSZ AGENCY Yavapai County Sheriff's Office  
DATE 7/3/11 TIME 10:59:39  
INTOXILYZER SERIAL # 80-01734 LOCATION Sulphur S.O. 103

- (✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution          AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (✓) 4. Air blank completed.
- (✓) 5. Calibration check completed. Test results 0.098 AC.
- (✓) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. MULLIGAN NSZ

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
07/03/2011

10:59:39

-----  
Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56  
-----

QAS: J. MURRAY #N56  
YAVAPAI YCSO  
-----

Operator: J. MURRAY #N56  
YAVAPAI YCSO  
-----

Test	g/210L	Time
Air Blank	0.000	11:00:13
0.100 Cal Check	0.098	11:00:34
Air Blank	0.000	11:01:04

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. MURRAY NSZ AGENCY Yuma County Sheriff's Office  
DATE 7/3/11 TIME 11:04:07  
INTOXILYZER SERIAL # 80-01734 LOCATION Selbyman S.O. 103

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

700 PSI  
Bottle # 779386

SIGNATURE J. MURRAY NSZ

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

07/03/2011

11:04:07

---

Standard Lot#: 779386

Last Changed By: J. MURRAY

#N56

---

QAS: J. MURRAY

#N56

YAVAPAI, YCSO

---

Operator: J. MURRAY

#N56

YAVAPAI YCSO

---

Subject: SQAP, TEST

DOB: 10/20/1960

Sex: F

Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	11:05:20
Diagnostic Test	Pass	11:05:55
Air Blank	0.000	11:06:23
0.100 Cal Check	0.099	11:06:43
Air Blank	0.000	11:07:13
Subject Test	0.000	11:08:16
Air Blank	0.000	11:08:44
Wait	ABT*	
Air Blank	RFI**	11:09:14

\*Sequence Aborted

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
07/03/2011

11:09:24

---

Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56

---

QAS: J. MURRAY #N56  
YAVAPAI YCSO

---

Operator: J. MURRAY #N56  
YAVAPAI YCSO

---

Subject: TEST,SQAP  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	11:10:06
Air Blank	RFI**	11:10:17

\*Improper Sample  
\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
07/03/2011

11:10:43

---

Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56

---

QAS: J. MURRAY #N56  
YAVAPAI YCSO

---

Operator: J. MURRAY #N56  
YAVAPAI YCSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	11:11:39
Diagnostic Test	Pass	11:12:14
Air Blank	0.000	11:12:41
0.100 Cal Check	0.098	11:13:02
Air Blank	0.000	11:13:31
Subject Test	0.148*	11:16:39
Air Blank	0.000	11:17:12
Air Blank	0.000	11:17:40
Subject Test	XXX**	11:18:13
Air Blank	0.000	11:18:48

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. M. V. NSB AGENCY Yavapai County Sheriff's Office  
DATE 7/3/11 TIME 11:19:11  
INTOXILYZER SERIAL # 80-01734 LOCATION Selbyman I.O. 103

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0.097 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. M. V. NSB

DPS Form Exh G-2 (Rev 05-01)

QA SPECIALIST \_\_\_\_\_

DATE \_\_\_\_\_

INTOXILYZER SERIAL # \_\_\_\_\_

1. \_\_\_\_\_

2. \_\_\_\_\_

3. \_\_\_\_\_

4. \_\_\_\_\_

5. \_\_\_\_\_

6. \_\_\_\_\_

7. \_\_\_\_\_

SIGNATURE \_\_\_\_\_

DPS Form Exh G-2

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
07/03/2011

11:19:11

-----  
Standard Lot#: 779386  
Last Changed By: J. MURRAY #N56  
-----

QAS: J. MURRAY #N56  
YAVAPAI YCSO  
-----

Operator: J. MURRAY #N56  
YAVAPAI YCSO  
-----

Test	g/210L	Time
Air Blank	0.000	11:19:45
0.100 Cal Check	0.097	11:20:06
Air Blank	0.000	11:20:36

Preventative Maintenance  
Performed -- Timer Reset