

COPY

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. MURPHY NCH/5597 AGENCY Yavapai County Sheriff's
DATE 3/31/12 TIME 13:47:39
INTOXILYZER SERIAL # 80-01734 LOCATION Selma 103

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0.098 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murphy

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
03/31/2012

13:47:39

Standard Lot#: 779386
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	13:48:14
0.100 Cal Check	0.098	13:48:35
Air Blank	0.000	13:49:05

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST J. Murray NSB/5597 AGENCY Yavapai County Sheriff's
DATE 3/31/12 TIME 13:49:27
INTOXILYZER SERIAL # 80-01734 LOCATION Seligerman 103

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SN# 729386 exp. 6/9/12
- 700 PSI

SIGNATURE J. Murray NSB/5597

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

03/31/2012

13:49:21

Standard Lot#: 779386

Last Changed By: J. MURRAY

#N56

QAS: J. MURRAY

#N56

YAVAPAI YCSO

Operator: J. MURRAY

#N56

YAVAPAI YCSO

Subject: SQAP, TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	13:50:19
Diagnostic Test	Pass	13:50:54
Air Blank	0.000	13:51:22
0.100 Cal Check	0.099	13:51:43
Air Blank	0.000	13:52:12
Subject Test	0.000	13:52:49
Air Blank	0.000	13:53:16
Wait	ABT*	
Air Blank	RFI**	13:53:42

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
03/31/2012

13:53:46

Standard Lot#: 779386
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Subject: SQAP, TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	13:54:23
Air Blank	RFI**	13:54:30

*Improper Sample

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
03/31/2012

13:55:04

Standard Lot#: 779386
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	13:56:00
Diagnostic Test	Pass	13:56:35
Air Blank	0.000	13:57:02
0.100 Cal Check	0.098	13:57:23
Air Blank	0.000	13:57:53
Subject Test	0.349*	14:01:00
Air Blank	0.000	14:01:34
Air Blank	0.000	14:02:02
Subject Test	XXX**	14:04:16
Air Blank	0.000	14:04:52

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. MURPHY NSB/5597 AGENCY Yavapai County Sheriff's
DATE 3/31/12 TIME 14:08:50
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman 103

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution, 100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
(X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
(X) 4. Air blank completed.
(X) 5. Calibration check completed. Test results 0. 098 AC.
(X) 6. Air blank completed.
(X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murphy

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
03/31/2012

14:08:50

Standard Lot#: 779386
Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56
YAVAPAI YCSO

Operator: J. MURRAY #N56
YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	14:09:25
0.100 Cal Check	0.098	14:09:46
Air Blank	0.000	14:10:16

Preventative Maintenance
Performed -- Timer Reset