

COPY

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NS6/5597 AGENCY Yavapai County Sheriff's Office
DATE 12/30/2012 TIME 11:57:44
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman 103

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0. 099 AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NS6

DPS Form Exh G-2 (Rev 05-01)

CALIBRATION
 CHECKED
 BY
 DATE
 TIME
 LOCATION
 OPERATOR
 INSTRUMENT
 TEST RESULTS
 COMMENTS

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

12/30/2012

11:57:44

Standard Lot#: 09312100A1

Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56

YAVAPAI YCSO

Operator: J. MURRAY #N56

YAVAPAI YCSO

Test g/210L Time

Air Blank 0.000 11:58:18
0.100 Cal Check 0.099 11:58:38
Air Blank 0.000 11:59:08

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

MURPHY MS6/5597 AGENCY Yavapai County Sheriff's Office
1/2012 TIME 12:01:26
#80-01734 LOCATION Seligman 103

PUSH BUTTON TO START"

DIAGNOSTIC TESTS
 Locking check.
 Air check.

OPERATIONAL TESTS

Subject test result 0. 000 AC.
 Logic system functioning.
 Successfully Completed Test Sequence printed
 Recognition system.
 Successfully Completed Test Sequence printed
 Print sample printed.
 Calibration Check standard 0. 100 AC. Result 0. 097 AC.
 Instrument properly and accurately. YES NO

93121 00A1 - 1000 PSI
exp. 6/1/2014

DIAGNOSTIC TESTS

SIGNATURE MURPHY
Date of check

DEPARTMENT OF PUBLIC SAFETY (REV 05-01)

Locking check

Air check

Subject test result

Logic system functioning

Recognition system

Print sample printed

Calibration Check standard

Instrument properly and accurately

Signature

Date of check

TOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Firmware Version: 8105.48
10/30/2012

12:01:26

Standard Lot#: 09312100A1
Last Changed By: J. MURRAY #N56

Operator: J. MURRAY #N56
WAPAI YCSO

Operator: J. MURRAY #N56
WAPAI YCSO

Project: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

5 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:02:32
Diagnostic Test	Pass	12:03:07
Air Blank	0.000	12:03:34
100 Cal Check	0.098	12:03:55
Air Blank	0.000	12:04:25
Subject Test	0.000	12:04:41
Air Blank	0.000	12:05:09
Wait	ABT*	
Air Blank	IPS**	12:05:23

Sequence Aborted
*Improper Sample

of a Successfully Completed Test Sequence

TOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Firmware Version: 8105.48
Date: 10/30/2012

12:05:31

Standard Lot#: 09312100A1
Last Changed By: J. MURRAY #N56

Operator: J. MURRAY #N56
Location: WAPAI YCSO

Operator: J. MURRAY #N56
Location: WAPAI YCSO

Subject: SQAP, TEST
DOB: 10/20/1960
Sex: F Weight: 115

5 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	RFI*	12:06:11
Air Blank	IPS**	12:06:19

RFI Detect
Improper Sample

5
Te
A Successfully Completed Test Sequence

OXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Firmware Version: 8105.48
Date: 10/30/2012

12:06:27

Standard Lot#: 09312100A1
Lot Changed By: J. MURRAY #N56

Operator: J. MURRAY #N56
APAI YCSO

Operator: J. MURRAY #N56
APAI YCSO

Subject: SOAP, TEST
Date: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:07:22
Diagnostic Test	Pass	12:07:57
Air Blank	0.000	12:08:25
100 Cal Check	0.098	12:08:46
Air Blank	0.000	12:09:15
Subject Test	DEF*	12:12:23
Air Blank	0.000	12:12:50
Air Blank	0.000	12:13:17
Subject Test	0.501**	12:16:25
Air Blank	0.000	12:17:02

Deficient Sample
Deficient Sample

Not a Successfully Completed Test Sequence

OXILYZER 8000
Station: YCSO SELIGMAN
Serial Number: 80-001734
Firmware Version: 8105.48
Date: 10/30/2012

12:17:05

Standard Lot#: 09312100A1
Last Changed By: J. MURRAY #N56

Operator: J. MURRAY #N56
APAI YCSO

Operator: J. MURRAY #N56
APAI YCSO

Subject: SQAP,TEST
Date: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:19:21
Diagnostic Test	Pass	12:19:56
Air Blank	0.000	12:20:23
100 Cal Check	0.098	12:20:44
Air Blank	0.000	12:21:13
Subject Test	XXX*	12:21:42
Air Blank	0.000	12:22:22

Invalid Sample
Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2

THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

OFFICER ST. MURRAY NS6/5597 AGENCY Yavapai County Sheriff's Office
DATE 3/12 TIME 12:22:35
INSTRUMENT SERIAL # 80-01734 LOCATION Seligman 103

- Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
- OR
- Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.5°C
- Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- Blank completed.
- Calibration check completed. Test results 0. 097 AC.
- Blank completed.
- Remove related record. Attach the record to the completed checklist.

SIGNATURE ST. MURRAY

DPS Form G-2 (Rev 05-01)

QUALITY ASSURANCE

DATE 3/12

INSTRUMENT SERIAL #

Ensure that

Pour a stand

simulator. E

Intoxilyzer

Go to int

Blank com

Blank com

SIGNATURE

DPS Form G-2 (Re

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

12/30/2012

12:22:35

Standard Lot#: 09312100A1

Last Changed By: J. MURRAY #N56

QAS: J. MURRAY #N56

YAVAPAI YCSO

Operator: J. MURRAY #N56

YAVAPAI YCSO

Test	g/210L	Time
Air Blank	0.000	12:23:12
0.100 Cal Check	0.097	12:23:32
Air Blank	0.000	12:24:02

Preventative Maintenance
Performed -- Timer Reset