



ARIZONA DEPARTMENT OF PUBLIC SAFETY  
INTOXILYZER MAINTENANCE REPORT

AGENCY Yavapai County Sheriff's Office  
Prescott, AZ 86301  
OFFICER MURRAY, #5597  
DATE September 24, 2014

CR NO. I800017340002

Page 1 of 1

COPY

INSTRUMENT:

80001734

INSTRUMENT LOCATION:

Yavapai County Sheriff's Office

MAINTENANCE REQUESTED:

Repair and Preventative Maintenance

MAINTENANCE PERFORMED:

*Parts Replaced:*

Flow Sensor, Power Supply

*Preventative Maintenance Performed:*

Inspection, Calibration, Verification

JOSEPH M SLOWINSKI, #6101  
Electronics Technician  
Central Regional Crime Laboratory  
2102 W. Encanto Blvd.  
Phoenix, AZ 85009  
(602) 223-2394





Arizona Department of Public Safety  
P. O. Box 6638, Mail Drop \_\_\_\_\_  
Phoenix, AZ 85005-6638

*"Courteous Vigilance"*

**Attn QAS: Please perform a 90 day SQAP before  
placing Intoxilyzer back in service.**

Intoxilyzer SN: 80-00 1734

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murphy NS6/5597 AGENCY Yavapai County Sheriff's Office  
DATE 9/29/2014 TIME 12:21:21  
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman

- (\*) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
Pour a standard alcohol concentration solution OR AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (2) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (2) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (4) 4. Air blank completed.
- (2) 5. Calibration check completed. Test results 0. 097 AC.
- (4) 6. Air blank completed.
- (2) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murphy NS6/5597

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

09/29/2014

12:21:21

-----  
Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56  
-----

QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS  
-----

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS  
-----

Test	g/210L	Time
Air Blank	0.000	12:22:03
0.100 Cal Check	0.097	12:22:24
Air Blank	0.000	12:22:54

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST MURRAY NSB/5597 AGENCY Yavapai County Sheriff's Office  
DATE 9/29/2014 TIME 12:23:08  
INTOXILYZER SERIAL # 80001734 LOCATION Seligman

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 096 AC.

Instrument is operating properly and accurately. YES  NO

COMMENTS

3391310043  
11/1/2016 7900PST

SIGNATURE J. Murray NSB/5597

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Comp Version: 8105.48

09/29/2004

12:23:08

Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56

Operator: J. MURRAY5597 #N56

YACAPAI SHERIFFS

Operator: J. MURRAY5597 #N56

YACAPAI SHERIFFS

Subject: SOAP, TEST

DOB: 10/20/1960

Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:24:03
Diagnostic Test	Pass	12:24:38
Air Blank	0.000	12:25:05
0.100 Cal Check	0.097	12:25:26
Air Blank	0.000	12:25:55
Subject Test	0.000	12:26:21
Air Blank	0.000	12:26:49
Wait	ABT*	
Air Blank	RFI**	12:27:05

\*Sequence Aborted

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Code Version: 8105.48

09/29/2004

12:27:11

Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56

Q/S: J. MURRAY5597 #N56

Y: APAL SHERIFFS

O/S: J. MURRAY5597 #N56

Y: APAL SHERIFFS

Subject: SOAP, TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	12:28:02
Air Blank	RFI**	12:28:09

\*Improper Sample

\*\*RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYNER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Cube Version: 8105.48

08/29/2014

12:28:34

Standard Lot#: 33913100A3

Last Changed By: J. MURRAY5597 #N56

O/S: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

Subject: SOAP, TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	12:29:29
Diagnostic Test	Pass	12:30:04
Air Blank	0.000	12:30:31
0.100 Cal Check	0.097	12:30:52
Air Blank	0.000	12:31:22
Subject Test	0.259*	12:34:29
Air Blank	0.000	12:35:01
Air Blank	0.000	12:35:28
Subject Test	XXX**	12:36:29
Air Blank	0.000	12:37:02

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. MURPHY NSB/5597 AGENCY Yavapai County Sheriff's Office  
DATE 9/29/2014 TIME 12:37:22  
INTOXILYZER SERIAL # 80-01734 LOCATION Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
Pour a standard alcohol concentration solution ✓ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.096 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. MURPHY NSB/5597

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48

08/29/2014

12:37:22

Standard Lot#: 33913100A3  
Last Changed By: J. MURRAY5597 #N56

Operator: J. MURRAY5597 #N56  
YUAPAI SHERIFFS

Operator: J. MURRAY5597 #N56  
YUAPAI SHERIFFS

Test	g/210L	Time
Air Blank	0.000	12:37:59
0.100 Cal Check	0.096	12:38:19
Air Blank	0.000	12:38:49

Preventative Maintenance  
Performed -- Timer Reset