

DR 17-042952

Copy

EXHIBIT G-2  
 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)  
 ARIZONA DEPARTMENT OF PUBLIC SAFETY  
 STANDARD QUALITY ASSURANCE PROCEDURES  
 INTOXILYZER MODEL 8000  
 STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO  
 DATE 12-1-17 TIME 21:56:53  
 INTOXILYZER SERIAL # 80-01734 LOCATION Seligman YCSO

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
 OR  
 Pour a standard alcohol concentration solution N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

DPS Form Exh G-2 (Rev 05-01)

Tank Serial # 0671700A5  
 Exp 5-5-2019  
 Prrs 1000 Asi

17-042952

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
12/01/2017

21:56:53

-----  
Standard Lot#: 0617100A5  
Last Changed By: S. BLAKLEY SR #L6861  
-----

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	21:57:24
0.100 Cal Check	0.098	21:57:45
Air Blank	0.000	21:58:14

Preventative Maintenance  
Performed -- Timer Reset

DR 17-042952

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Scott Blakley Sr AGENCY Yavapai County SO  
DATE 12-1-17 TIME 22:00:18  
INTOXILYZER SERIAL # 80-01734 LOCATION YPSO Seligman

(X) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (X) 1. Clock time check.
- (X) 2. Date check.

OPERATIONAL TESTS

- (X) 1. Alcohol-free subject test result 0. 000 AC.
- (X) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- (X) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (X) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 098 AC.

Instrument is operating properly and accurately. YES X NO     

COMMENTS

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

SIGNATURE Scott Blakley Sr

17-042952

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
12/01/2017

22:00:18

---

Standard Lot#: 0617100A5  
Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	22:01:17
Diagnostic Test	Pass	22:01:52
Air Blank	0.000	22:02:20
0.100 Cal Check	0.099	22:02:40
Air Blank	0.000	22:03:10
Subject Test	0.000	22:03:26
Air Blank	0.000	22:03:53
Wait	ABT*	
Air Blank	0.000	22:04:34

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

17-042952

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
12/01/2017

22:05:10

---

Standard Lot#: 0617100A5  
Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	22:05:56
Air Blank	RFI**	22:06:11

\*Improper Sample

\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

17-042952

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
12/01/2017

22:10:49

---

Standard Lot#: 0617100A5  
Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	22:11:47
Diagnostic Test	Pass	22:12:22
Air Blank	0.000	22:12:50
0.100 Cal Check	0.098	22:13:10
Air Blank	0.000	22:13:40
Subject Test	0.074*	22:16:47
Air Blank	0.000	22:17:19
Air Blank	0.000	22:17:46
Subject Test	XXX**	22:18:03
Air Blank	0.000	22:18:36

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO  
DATE 12-1-17 TIME 22:19:30  
INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

17-042952

INTOXILYZER 8000  
Location: YCSO SELIGMAN  
Serial Number: 80-001734  
Core Version: 8105.48  
12/01/2017

22:19:30

-----  
Standard Lot#: 0617100A5  
Last Changed By: S. BLAKLEY SR #L6861  
-----

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	22:20:00
0.100 Cal Check	0.098	22:20:21
Air Blank	0.000	22:20:50

Preventative Maintenance  
Performed -- Timer Reset

17-042952



ARIZONA DEPARTMENT OF PUBLIC SAFETY  
INTOXILYZER MAINTENANCE REPORT

CR NO. I800017340005

Page 1 of 1

AGENCY Yavapai County Sheriff's Office  
Prescott, AZ 86301  
OFFICER BLAKLEY, #6861  
DATE November 20, 2017



INSTRUMENT

80001734

INSTRUMENT LOCATION

Yavapai County Sheriff's Office

MAINTENANCE REQUESTED

Preventative Maintenance

MAINTENANCE PERFORMED

*Preventative Maintenance Performed:*

Inspection, Calibration, Verification

*Erin E. Boone*

---

ERIN E. BOONE, #5823, Forensic Scientist  
Central Regional Crime Laboratory  
2102 W. Encanto Blvd., Phoenix, AZ 85009  
602-223-2281