

DR 17-04524)

Copy

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO

DATE 12-19-17 TIME 22:41:47

INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.099 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

DPS Form Exh G-2 (Rev 05-01)

Tank Serial # 06717100A5

Exp 5-5-2019

PPS 1000 psi

17-045241

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

12/19/2017

22:41:47

-----  
Standard Lot#: 0617100A5

Last Changed By: S. BLAKLEY SR #L6861

-----  
QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

-----  
Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      22:42:49  
0.100 Cal Check                0.099                      22:43:10  
Air Blank                      0.000                      22:43:39

Preventative Maintenance  
Performed -- Timer Reset