

COPY

DR 18-015820

EXHIBIT G-2
 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)
 ARIZONA DEPARTMENT OF PUBLIC SAFETY
 STANDARD QUALITY ASSURANCE PROCEDURES
 INTOXILYZER MODEL 8000
 STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO
 DATE 5-7-18 TIME 21:09:39
 INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
 OR
 Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 098 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

DPS Form Exh G-2 (Rev 05-01)

Tank Serial # 06717108A5
 Exp 5-5-2019
 Press 950 psi

DR18-015820 -

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

05/02/2018

21:09:39

Standard Lot#: 0617100A5

Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	21:10:13
0.100 Cal Check	0.098	21:10:34
Air Blank	0.000	21:11:04

Preventative Maintenance
Performed -- Timer Reset

DR 18-015820

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-164 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Scott Blackley Sr. AGENCY Yavapai County SO

DATE 5-2-18 TIME 21:11:27

INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.

2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0.000 AC.

2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed

3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.

4. Standard Calibration Check standard 0.100 AC. Result 0.097 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

SIGNATURE Scott Blackley Sr.

DR 18-015820

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
05/02/2018

21:11:27

Standard Lot#: 0617100A5
Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:12:29
Diagnostic Test	Pass	21:13:04
Air Blank	0.000	21:13:31
0.100 Cal Check	0.098	21:13:52
Air Blank	0.000	21:14:21
Subject Test	0.000	21:14:44
Air Blank	0.000	21:15:12
Wait	ABT*	
Air Blank	0.000	21:15:48

*Sequence Aborted

Not a Successfully Completed Test Sequence

DR 18-015820

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
05/02/2018

21:17:31

Standard Lot#: 0617100A5
Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP,TEST
DOB: 10/20/1960
Sex: F Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	IPS*	21:18:16
Air Blank	RFI**	21:18:29

*Improper Sample
**RFI Detect

Not a Successfully Completed Test Sequence

DR 18-015820

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
05/02/2018

21:19:06

Standard Lot#: 0617100A5
Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Subject: SQAP,TEST

DOB: 10/20/1960

Sex: F

Weight: 115

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	21:20:01
Diagnostic Test	Pass	21:20:36
Air Blank	0.000	21:21:03
0.100 Cal Check	0.098	21:21:24
Air Blank	0.000	21:21:53
Subject Test	0.065*	21:25:01
Air Blank	0.000	21:25:33
Air Blank	0.000	21:26:00
Subject Test	XXX**	21:26:19
Air Blank	0.000	21:26:52

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

DR 18-015820

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY

STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO
DATE 5-2-18 TIME 21:27:57
INTOXILYZER SERIAL # 80-01734 LOCATION YCSO Seligman

- (x) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
OR
Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (x) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (x) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (x) 4. Air blank completed.
- (x) 5. Calibration check completed. Test results 0.097 AC.
- (x) 6. Air blank completed.
- (x) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

DT 18-015820

INTOXILYZER 8000
Location: YCSO SELIGMAN
Serial Number: 80-001734
Core Version: 8105.48
05/02/2018 21:27:57

Standard Lot#: 0617100A5
Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861
YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	21:28:27
0.100 Cal Check	0.097	21:28:47
Air Blank	0.000	21:29:17

Preventative Maintenance
Performed -- Timer Reset