

Copy

DR18-027369

EXHIBIT G-2
 THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)
 ARIZONA DEPARTMENT OF PUBLIC SAFETY
 STANDARD QUALITY ASSURANCE PROCEDURES
 INTOXILYZER MODEL 8000
 STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr AGENCY Yavapai County SD
 DATE 7-24-18 TIME 20:06:48
 INTOXILYZER SERIAL # 80-01734 LOCATION DPSO Seligman

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.
 OR
 Pour a standard alcohol concentration solution 111 AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.097 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr

DPS Form Exh G-2 (Rev 05-01)

Tank Serial # 0671700A5
 EPA ~~05-05-2019~~
 Pres 850 psi

DR 18 027369

INTOXILYZER 8000

Location: YCSO SELIGMAN

Serial Number: 80-001734

Core Version: 8105.48

07/24/2018

20:06:48

Standard Lot#: 0617100A5

Last Changed By: S. BLAKLEY SR #L6861

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	20:07:25
0.100 Cal Check	0.097	20:07:46
Air Blank	0.000	20:08:15

Preventative Maintenance
Performed -- Timer Reset