

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST J. Murray NSB AGENCY Yavapai County Sheriff's  
DATE 2/19/12 TIME 6:53:18  
INTOXILYZER SERIAL # 80-000289 LOCATION Pascott 103

- 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .10%  
OR  
Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- 4. Air blank completed.
- 5. Calibration check completed. Test results 0.0% AC.
- 6. Air blank completed.
- 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB

INTOXILYZER 8000

Location: YAVAPAI CO. SHERIFF

Serial Number: 80-000289

Core Version: 8105.48

02/19/2012

06:53:18

-----  
Standard Lot#: 01011100A1

Last Changed By: J. MURRAY #N56  
-----

QAS: J. MURRAY #N56

YAVAPAI YCSO  
-----

Operator: J. MURRAY #N56

YAVAPAI YCSO  
-----

Test	g/210L	Time
Air Blank	0.000	06:54:02
0.100 Cal Check	0.096	06:54:23
Air Blank	0.000	06:54:52

Preventative Maintenance  
Performed -- Timer Reset