

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.

DATE 9/11/13 TIME 0006

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO RUI TRAILER

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC; into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 090 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

INTOXILYZER 8000
Location: YCSO DUI TRAILER
Serial Number: 80-000299
Core Version: 8105.48
09/01/2013 00:06:18

Standard Lot#: 13712100A2
Last Changed By: L. MOODY #7486

OAS: L. MOODY #7486
YAUAPAI CSO

Operator: L. MOODY #7486
YAUAPAI CSO

Test	g/210L	Time
Air Blank	0.000	00:06:47
0.100 Cal Check	0.090	00:07:08
Air Blank	0.000	00:07:37

Preventative Maintenance
Performed -- Timer Reset

