

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST LOGAN MOODY AGENCY YAVAPAI CO. S.O.  
DATE 11/14/2013 TIME 1238  
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO DUI VAN

- (M) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.  
OR  
~~Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (M) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"  
(M) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.  
(M) 4. Air blank completed.  
(M) 5. Calibration check completed. Test results 0. 091 AC.  
(M) 6. Air blank completed.  
(M) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

INTOXILYZER 8000  
Location: YCSO DUI TRAILER  
Serial Number: 80-000289  
Core Version: 8105.48  
11/14/2013 12:38:06

-----  
Standard Lot#: 13712100A2  
Last Changed By: L. MOODY #7486  
-----

OAS: L. MOODY #7486  
YAUAPAI CSO  
-----

Operator: L. MOODY #7486  
YAUAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	12:38:41
0.100 Cal Check	0.091	12:39:02
Air Blank	0.000	12:39:31

Preventative Maintenance  
Performed -- Timer Reset