

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Kelly Lowland AGENCY YCSO YAVAPAI COUNTY
DATE 04/28/15 TIME 0056
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO BLACK CANYON

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .10 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0.101 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Kelly Lowland 984

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
04/26/2015 00:56:45

Standard Lot#: 25414100A4
Last Changed By: L. MOODY #7486

OAS: K. WOHLWEND #9811
YAVAPAI CO SO

Operator: K. WOHLWEND #9811
YAVAPAI CO SO

Test	g/210L	Time
Air Blank	0.000	00:57:30
0.100 Cal Check	0.101	00:57:50
Air Blank	0.000	00:58:20

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST KELLY WOHLEND AGENCY YAVAPAI CO SO
DATE 04/28/15 TIME 1059
INTOXILYZER SERIAL # 80-000289 LOCATION YCSO BLACK CANYON

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

1. Clock time check.
 2. Date check.

OPERATIONAL TESTS

1. Alcohol-free subject test result 0. 000 AC.
 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
 4. Standard Calibration Check standard 0. 100 AC. Result 0. 100 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS

ALL TESTS COMPLETED INCIDENT FREE

SIGNATURE

Kelly Wohle 9811

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
04/28/2015 00:59:58

Standard Lot#: 25414100A4
Last Changed By: L. MOODY #7496

OAS: K. WOHLWEND #9811
YAUAPA! CO 50

Operator: K. WOHLWEND #9811
YAUAPA! CO 50

Subject: TEST,SQUAP
DOB: 04/28/2000
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	01:01:12
Diagnostic Test	Pass	01:01:49
Air Blank	0.000	01:02:17
0.100 Cal Check	0.100	01:02:37
Air Blank	0.000	01:03:07
Subject Test	0.000	01:03:25
Air Blank	ABT*	01:03:34
Air Blank	IPS**	01:03:41

*Sequence Aborted
**Improper Sample

Not a Successfully
Completed
Test Sequence

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
04/28/2015 01:04:00

Standard Lot#: 25414100A4
Last Changed By: L. MOODY #7486

OAS: K. WOHLWEND #9811
YAUAPA! CO 50

Operator: K. WOHLWEND #9811
YAUAPA! CO 50

Subject: TEST,SQUAP
DOB: 04/28/2000
Sex: M Weight: 111

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	01:05:05
Diagnostic Test	Pass	01:05:43
Air Blank	0.000	01:06:10
0.100 Cal Check	0.101	01:06:31
Air Blank	0.000	01:07:01
Subject Test	0.036*	01:10:08
Air Blank	0.000	01:10:39
Air Blank	0.000	01:11:07
Subject Test	XXX**	01:11:35
Air Blank	RFI***	01:11:46

*Deficient Sample
**Invalid Sample
Begin new deprivation period
***RFI Detect

Not a Successfully
Completed
Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST RELLY WSHLEWAS AGENCY YAVAPAI CO. SO
DATE 04/28/15 TIME 0112
INTOXILYZER SERIAL # 80-000 289 LOCATION YCSO BLACK CANYON

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution, 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 100 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE [Signature] 9801

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
04/28/2015 01:12:28

Standard Lot#: 25414100A4
Last Changed By: L. MOODY #7486

QAS: K. WOHLWEND #9811
YAVAPAI CO SO

Operator: K. WOHLWEND #9811
YAVAPAI CO SO

Test	g/210L	Time
Air Blank	0.000	01:12:58
0.100 Cal Check	0.100	01:13:19
Air Blank	0.000	01:13:49

Preventative Maintenance
Performed -- Timer Reset