

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 09/01/2018 TIME 0922

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

- (lu) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (lu) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (lu) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (lu) 4. Air blank completed.
- (lu) 5. Calibration check completed. Test results 0. 096 AC.
- (lu) 6. Air blank completed.
- (lu) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody #7486

18-032380

INTOXILYZER 8000
Location: YCSO - BLACK CANYON
Serial Number: 80-000289
Core Version: 8105.48
09/01/2018 09:22:32

Standard Lot#: 23016100A1
Last Changed By: L. MOODY #7486

QAS: L. MOODY #7486
YAVAPAI CSO

Operator: L. MOODY #7486
YAVAPAI CSO

Test	g/210L	Time
Air Blank	0.000	09:23:00
0.100 Cal Check	0.096	09:23:21
Air Blank	0.000	09:23:51

Preventative Maintenance
Performed -- Timer Reset

EXHIBIT G-4
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 09/01/2018 TIME 0926

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- 1. Clock time check.
- 2. Date check.

OPERATIONAL TESTS

- 1. Alcohol-free subject test result 0. 000 AC.
- 2. Error recognition logic system functioning.
Not a Successfully Completed Test Sequence printed
- 3. Proper sample recognition system.
Not a Successfully Completed Test Sequence printed
Deficient sample printed.
- 4. Standard Calibration Check standard 0. 100 AC. Result 0. 095 AC.

Instrument is operating properly and accurately. YES NO

COMMENTS 850psi

SIGNATURE Logan Moody 7486

18-032380

INTOXILYZER 8000

Location: YCSO - BLACK CANYON

Serial Number: 80-000289

Core Version: 8105.48

09/01/2018

09:26:24

Standard Lot#: 23016100A1

Last Changed By: L. MOODY

#7486

QAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:27:20
Diagnostic Test	Pass	09:27:55
Air Blank	0.000	09:28:22
0.100 Cal Check	0.095	09:28:43
Air Blank	0.000	09:29:12
Subject Test	0.000	09:29:48
Air Blank	ABT*	09:29:55
Air Blank	RFI**	09:30:02

*Sequence Aborted

**RFI Detect

Not a Successfully Completed Test Sequence

INTOXILYZER 8000

Location: YCSO - BLACK CANYON

Serial Number: 80-000289

Core Version: 8105.48

09/01/2018

09:31:55

Standard Lot#: 23016100A1

Last Changed By: L. MOODY

#7486

QAS: L. MOODY

#7486

YAVAPAI CSO

Operator: L. MOODY

#7486

YAVAPAI CSO

Subject: SQAP,TEST

DOB: 01/01/1990

Sex: M

Weight: 200

15 Minute Deprivation Period? Yes

Test	g/210L	Time
Air Blank	0.000	09:32:45
Diagnostic Test	Pass	09:33:19
Air Blank	0.000	09:33:47
0.100 Cal Check	0.096	09:34:08
Air Blank	0.000	09:34:37
Subject Test	0.056*	09:37:44
Air Blank	0.000	09:38:16
Air Blank	0.000	09:38:43
Subject Test	XXX**	09:39:16
Air Blank	0.000	09:39:48

*Deficient Sample

**Invalid Sample

Begin new deprivation period

Not a Successfully Completed Test Sequence

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Logan Moody #7486 AGENCY Yavapai County Sheriff's Office

DATE 09/01/2018 TIME 0940

INTOXILYZER SERIAL # 80-000289 LOCATION YCSO - Black Canyon

- (L) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
~~Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C~~
- (S) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (S) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (S) 4. Air blank completed.
- (S) 5. Calibration check completed. Test results 0. 095 AC.
- (S) 6. Air blank completed.
- (S) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Logan Moody

