

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Cpl. H. MORRIS #50 AGENCY PRESOTT VALLEY P.D.

DATE 02-09-09 TIME 0636

INTOXILYZER SERIAL # 80-000293 LOCATION P.V. P.D.

- (PASS) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .180 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (PASS) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (PASS) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (PASS) 4. Air blank completed.
- (PASS) 5. Calibration check completed. Test results 0. 100 AC.
- (PASS) 6. Air blank completed.
- (PASS) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Cpl. H. MORRIS #50

DPS Form Exh G-2 (Rev 05-01)

WITH DEPARTMENT RE-ALIGNMENT, I WILL NOW BE TAKING OVER AS THE PRIMARY DEPT. QAS. I WAS CONTACTED LAST NIGHT BY ON-DUTY SUPERVISOR, THE INTOX 8000 (80-000293) WAS DISPLAYING, "CONTACT QAS" FOR SERVICE. THIS MORNING (02-09-09) A CALIBRATION CHECK WAS PERFORMED.

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

02/09/2009

06:36:55

Standard Lot#: 80441F

Last Changed By: J. TOBIN #73

QAS: M. MORRIS #50

PRESCOTT VALLEY PD

Test	g/210L	Time
Air Blank	0.000	06:37:23
Cal Check	0.100	06:37:42
Air Blank	0.000	06:38:11

C. M. P. D. M. #50
Operator's Signature QAS# 33034