

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST T. LAWRENCE AGENCY PRESOTT VALLEY PD
DATE 9/26/15 TIME 1452
INTOXILYZER SERIAL # 80-000293 LOCATION PRESOTT VALLEY PD/BOOKING ROOM

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.
OR
Pour a standard alcohol concentration solution _____ AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0. 097 AC.
- () 6. Air blank completed.
- () 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE _____ #61

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

Core Version: 8105.48

09/26/2015

14:52:57

Standard Lot#: 26614100A6

Last Changed By: A. LAWRENCE #61

QAS: A. LAWRENCE #61

PRESCOTT VALLEY PD

Operator: A. LAWRENCE #61

PRESCOTT VALLEY PD

| Test | g/210L | Time |
|-----------------|--------|----------|
| Air Blank | 0.000 | 14:53:29 |
| 0.100 Cal Check | 0.097 | 14:53:50 |
| Air Blank | 0.000 | 14:54:19 |

Preventative Maintenance
Performed -- Timer Reset

