

INTOXILYZER 8000

Location: PRESCOTT VALLEY PD

Serial Number: 80-000293

Core Version: 8105.48

11/08/2018

13:10:36

-----  
Standard Lot#: 10818100A2

Last Changed By: T. TEST #0000  
-----

QAS: B. PENNER #29

PRESCOTT VALLEY PD  
-----

Operator: B. PENNER #29

PRESCOTT VALLEY PD  
-----

Test	g/210L	Time
Air Blank	0.000	13:11:47
0.100 Cal Check	0.099	13:12:08
Air Blank	0.000	13:12:37

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104(A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST B. PENNER #29 AGENCY PRESOTT VALLEY PD  
DATE 11-8-18 TIME 1310  
INTOXILYZER SERIAL # 80-000293 LOCATION PVPP MAIN-HOLDING

(✓) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.

OR

Pour a standard alcohol concentration solution \_\_\_\_\_ AC, into a clean dry simulator and assemble the simulator.

Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34 \pm 0.2 \text{ C}$

(✓) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"

(✓) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.

(✓) 4. Air blank completed.

(✓) 5. Calibration check completed. Test results 0. 099 AC.

(✓) 6. Air blank completed.

(✓) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE  #29