

COPY

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Murray NSB AGENCY Yavapai County Sheriff's Office  
DATE 7/7/14 TIME 09:39:45  
INTOXILYZER SERIAL # 80-006228 LOCATION DUI Truck

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 100 AC.  
OR  
Pour a standard alcohol concentration solution        AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach 34°C ± 0.2°C
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0. 099 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE J. Murray NSB / 5597

INTOXILYZER 8000

Location: YAVAPAI COUNTY SO

Serial Number: 80-006228

Core Version: 8105.48

07/07/2014

09:39:45

-----  
Standard Lot#: 12

Last Changed By: 1. 1 #1

-----  
QAS: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

-----  
Operator: J. MURRAY5597 #N56

YAVAPAI SHERIFFS

-----  
Test                      g/210L                      Time  
-----  
Air Blank                      0.000                      09:40:24  
0.100 Cal Check                0.099                      09:40:45  
Air Blank                      0.000                      09:41:14

Preventative Maintenance  
Performed -- Timer Reset