

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000  
STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO

DATE 2-15-18 TIME 21:07:31

INTOXILYZER SERIAL # 80-006228 LOCATION YCSCO DUI Truck

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.099 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr.

Tank Serial # 06717100A5  
Exp 5-5-2019  
Pres 1000 psi

DR-18-085817

INTOXILYZER 8000  
Location: YAVAPAI COUNTY SO  
Serial Number: 80-006228  
Core Version: 8105.48  
02/15/2018 21:07:31

-----  
Standard Lot#: 06717100A5  
Last Changed By: S. BLAKLEY SR #L6861

-----  
QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

-----  
Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

-----  
Test g/210L Time  
-----  
Air Blank 0.000 21:08:01  
0.100 Cal Check 0.099 21:08:22  
Air Blank 0.000 21:08:51

Preventative Maintenance  
Performed -- Timer Reset

EXHIBIT G-4  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD QUALITY ASSURANCE PROCEDURE

QA SPECIALIST Scott Blakley Sr. AGENCY Yavapai County SO  
DATE 2-15-18 TIME 21:10:21  
INTOXILYZER SERIAL # 80-006228 LOCATION YCSO DUI Truck

(X) 1. Display Reads "PUSH BUTTON TO START"

DIAGNOSTIC TESTS

- (X) 1. Clock time check.
- (X) 2. Date check.

OPERATIONAL TESTS

- (X) 1. Alcohol-free subject test result 0. 000 AC.
- (X) 2. Error recognition logic system functioning.  
Not a Successfully Completed Test Sequence printed
- (X) 3. Proper sample recognition system.  
Not a Successfully Completed Test Sequence printed  
Deficient sample printed.
- (X) 4. Standard Calibration Check standard 0. 100 AC. Result 0. 097 AC.

Instrument is operating properly and accurately. YES X NO     

COMMENTS

Instrument Taken out of Service. To be sent to DPS for Service  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

SIGNATURE Scott Blakley Sr.

DIR 18-005817

INTOXILYZER 8000  
Location: YAVAPAI COUNTY SO  
Serial Number: 80-006228  
Core Version: 8105.48  
02/15/2018 21:10:21

---

Standard Lot#: 06717100A5  
Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	21:11:32
Diagnostic Test	Pass	21:12:07
Air Blank	0.000	21:12:34
0.100 Cal Check	0.098	21:12:55
Air Blank	0.000	21:13:24
Subject Test	0.000	21:13:41
Air Blank	0.000	21:14:08
Wait	ABT*	
Air Blank	0.000	21:14:46

\*Sequence Aborted

**Not a Successfully Completed Test Sequence**

DR 18-005817

INTOXILYZER 8000

Location: YAVAPAI COUNTY SO

Serial Number: 80-006228

Core Version: 8105.48

02/15/2018

21:15:31

---

Standard Lot#: 06717100A5

Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861

YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861

YAVAPAI CSO

---

Subject: SQAP,TEST

DOB: 10/20/1960

Sex: F

Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	IPS*	21:16:16
Air Blank	RFI**	21:16:30

\*Improper Sample

\*\*RFI Detect

**Not a Successfully Completed Test Sequence**

DR18-005817

INTOXILYZER 8000  
Location: YAVAPAI COUNTY SO  
Serial Number: 80-006228  
Core Version: 8105.48  
02/15/2018 21:17:38

---

Standard Lot#: 06717100A5  
Last Changed By: S. BLAKLEY SR #L6861

---

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO

---

Subject: SQAP,TEST  
DOB: 10/20/1960  
Sex: F Weight: 115

---

15 Minute Deprivation Period? Yes

---

Test	g/210L	Time
Air Blank	0.000	21:18:33
Diagnostic Test	Pass	21:19:08
Air Blank	0.000	21:19:35
0.100 Cal Check	0.100	21:19:56
Air Blank	0.000	21:20:25
Subject Test	0.026*	21:23:33
Air Blank	0.000	21:24:05
Air Blank	0.000	21:24:32
Subject Test	XXX**	21:24:52
Air Blank	0.000	21:25:26

\*Deficient Sample

\*\*Invalid Sample

Begin new deprivation period

**Not a Successfully Completed Test Sequence**

DR 18-005817

INTOXILYZER 8000  
Location: YAVAPAI COUNTY SO  
Serial Number: 80-006228  
Core Version: 8105.48  
02/15/2018 21:26:09

-----  
Standard Lot#: 06717100A5  
Last Changed By: S. BLAKLEY SR #L6861  
-----

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	21:26:39
0.100 Cal Check	0.097	21:26:59
Air Blank	0.000	21:27:29

Preventative Maintenance  
Performed -- Timer Reset

DR 18-005817

EXHIBIT G-2  
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY  
STANDARD QUALITY ASSURANCE PROCEDURES  
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST Scott Blakley Sr AGENCY Yavapai County SO

DATE 2-15-18 TIME 21:28:30

INTOXILYZER SERIAL # 80-006228 LOCATION YCSO DUI Truck

- (X) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution 0.100 AC.  
OR  
Pour a standard alcohol concentration solution NA AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach  $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (X) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (X) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (X) 4. Air blank completed.
- (X) 5. Calibration check completed. Test results 0.097 AC.
- (X) 6. Air blank completed.
- (X) 7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE Scott Blakley Sr

DR 18-005817

INTOXILYZER 8000  
Location: YAVAPAI COUNTY SO  
Serial Number: 80-006228  
Core Version: 8105.48  
02/15/2018 21:28:30

-----  
Standard Lot#: 06717100A5  
Last Changed By: S. BLAKLEY SR #L6861  
-----

QAS: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Operator: S. BLAKLEY SR #L6861  
YAVAPAI CSO  
-----

Test	g/210L	Time
Air Blank	0.000	21:28:59
0.100 Cal Check	0.097	21:29:20
Air Blank	0.000	21:29:50

Preventative Maintenance  
Performed -- Timer Reset