

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST T. A. [Signature] AGENCY Prescott PD

DATE 02/15/17 TIME 0544

INTOXILYZER SERIAL # 80-006230 LOCATION Prescott PD

- () 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution _____ AC. into a clean-dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- () 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- () 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- () 4. Air blank completed.
- () 5. Calibration check completed. Test results 0.099 AC.
- () 6. Air blank completed.
- () 7. Remove printed record; Attach the record to the completed checklist.

SIGNATURE [Signature]

DPS Form Exh G-2 (Rev. 05-01)

Observed: CAL CHECK OUT OF TOLL MACHINES PRIOR, DWI THIS
G-2 PRIOR TO SUBJECT TEST & ALL CORRECT.

INTOXILYZER 8000

Location: PRESCOTT PD

Serial Number: 80-006230

Core Version: 8105.48

02/15/2017

05:44:16

Standard Lot#: 27016100A1

Last Changed By: S. HILTON #372

QAS: T. ATTENBERGER #252

PRESCOTT PD

Operator: T. ATTENBERGER #252

PRESCOTT PD

Test	g/210L	Time
Air Blank	0.000	05:44:56
0.100 Cal Check	0.099	05:45:17
Air Blank	0.000	05:45:47

Preventative Maintenance
Performed -- Timer Reset

A handwritten signature in black ink, appearing to read 'T. Attenberger #252', is written across the lower middle of the page.