

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST S. HERNANDEZ AGENCY PCT P.D.
DATE 12/13/17 TIME 1300
INTOXILYZER SERIAL # 80-006230 LOCATION 222 S. MARINA ST.

1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution .100 AC.
OR
Pour a standard alcohol concentration solution AC, into a clean dry simulator and assemble the simulator. ~~Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$~~
2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
4. Air blank completed.
5. Calibration check completed. Test results 0. 100 AC.
6. Air blank completed.
7. Remove printed record. Attach the record to the completed checklist.

SIGNATURE S. HERNANDEZ

DPS Form Exh G-2 (Rev 05-01)

INTOXILYZER 8000
Location: PRESCOTT PD
Serial Number: 80-006230
Core Version: 8105.48
12/13/2017 13:00:37

Standard Lot#: 27016100A1
Last Changed By: S. HILTON #372

QAS: S. HILTON #372
PRESCOTT PD

Operator: S. HILTON #372
PRESCOTT PD

Test	g/210L	Time
Air Blank	0.000	13:01:10
0.100 Cal Check	0.100	13:01:31
Air Blank	0.000	13:02:00

Preventative Maintenance
Performed -- Timer Reset