

EXHIBIT G-2
THIS REPORT PREPARED PURSUANT TO DUTY IMPOSED BY A.A.C. R-13-10-104 (A)

ARIZONA DEPARTMENT OF PUBLIC SAFETY
STANDARD QUALITY ASSURANCE PROCEDURES
INTOXILYZER MODEL 8000

STANDARD CALIBRATION CHECK PROCEDURE

QA SPECIALIST KEVIN HUSPETH AGENCY SEDONA POLICE DEPARTMENT
DATE 07/08/2018 TIME 2258
INTOXILYZER SERIAL # 80-000924 LOCATION SEDONA POLICE DEPARTMENT

- (KH) 1. Ensure that gas tank is attached to instrument and contains a standard alcohol concentration solution . 100 AC.
Pour a standard alcohol concentration solution . ^{QR} N/A AC, into a clean dry simulator and assemble the simulator. Ensure that a tight seal has been made. Turn on the simulator and allow temperature to reach $34^{\circ}\text{C} \pm 0.2^{\circ}\text{C}$
- (KH) 2. Intoxilyzer 8000 display reads "PUSH BUTTON TO START"
- (KH) 3. Go to the "Control Testing Menu". Select "D" for dry control test or "W" for wet control test. After selection is made press ENTER.
- (KH) 4. Air blank complete.
- (KH) 5. Calibration check complete. Test results 0. 098 AC.
- (KH) 6. Air blank complete.
- (KH) 7. Remove printed record. Attach the record to the complete checklist.

SIGNATURE

[Signature] #474 PASSED

DPS Form Exb G-2 (Rev 05-01)

I hereby certify that the above and foregoing is a true and correct copy of the record of periodic maintenance for the Intoxilyzer 8000 referenced therein maintained by the Sedona Police Department pursuant to the requirements of the Arizona Department of Public Safety.

Date this 8TH day of July 2018

[Signature] #474
Quality Assurance Specialist

INTOXILYZER 8000
Location: SEDONA
Serial Number: 80-000924
Core Version: 8105.48
07/08/2018

22:58:37

Standard Lot#: 3491710A1
Last Changed By: W. LOPEZ #30

QAS: K. HUDSPETH #474
SEDONA PD

Operator: K. HUDSPETH #474
SEDONA PD

Test	g/210L	Time
Air Blank	0.000	22:59:57
0.100 Cal Check	0.098	23:00:18
Air Blank	0.000	23:00:47

K. Hudspeth #474 **ALL PASSED**

Preventative Maintenance
Performed -- Timer Reset

I hereby certify that the above and foregoing is a true and correct copy of the record of periodic maintenance for the intoxilyzer 8000 referenced therein maintained by the Sedona Police Department pursuant to the requirements of the Arizona Department of Public Safety.

Date this 8TH day of JULY, 2018

K. Hudspeth #474

Quality Assurance Specialist